

# KORAWALL

Direct WVD 24 V DC

Energy WVE 230 V AC



**CZ** **MONTÁŽNÍ NÁVOD** KORAWALL (Direct WVD, Energy WVE) – instalace, provoz, servis a údržba


**SK** **NÁVOD NA MONTÁŽ** KORAWALL (Direct WVD, Energy WVE) – inštalácia, prevádzka, servis a údržba

**EN** **INSTALLATION INSTRUCTIONS** KORAWALL (Direct WVD, Energy WVE) – installation, operation, service and maintenance

**DE** **MONTAGEANLEITUNG** KORAWALL (Direct WVD, Energy WVE) – Installation, Betrieb, Service und Wartung

**FR** **INSTRUCTIONS D'INSTALLATION** KORAWALL (Direct WVD, Energy WVE) – installation, fonctionnement, entretien et maintenance

**RU** **ИНСТРУКЦИЯ ПО МОНТАЖУ** KORAWALL (Direct WVD, Energy WVE) – установка, эксплуатация, сервис и техническое обслуживание



**HLK**  
STUTTGART

EN **442** EURONORM

**KORADO**

**LICON**   
member of KORADO Group

## Basic information

### Introduction

Explanation of symbols

### Safety

- Correct use of the WVD and WVE convector
- Safety instructions
- Personnel Qualification
- Risk of electric shock!
- General
- Protection against frost
- The right operating environment
- Commissioning
- General

### Technical parameters

- Contents of standard WVD delivery
- Optional accessories
- Contents of standard WVE delivery
- Optional accessories
- Mounting dimensions

## Installation – connection to the heating system

### Installation of the convector

- Construction part
- Connection to the heating system
- Connection to the WVD electrical system
- Connection to the WVE electrical system

### Check before the first start-up

### Service

- Function description
- Commissioning
- Fan speed selection
- Changing the “heating/cooling” mode
- “Heating” mode
- “Cooling” mode

### Maintenance

### Equipment malfunctions

- Diagnostic mode
- Primary initialization did not take place
- Fans do not work – “heating” mode
- Fans not working – “cooling” mode
- Old electrical and electronic equipment

## Assembly – construction part

<b>Introduction</b>	<b>32</b>	<b>Connection to elbow LM-valve</b>	<b>80</b>
Explanation of symbols	32	<b>Connection to straight LM-valve</b>	<b>88</b>
<b>Safety</b>	<b>32</b>	<b>Mounting of the front cover WVD</b>	<b>96</b>
Correct use of the WVD and WVE convector	32	<b>Mounting of the front cover WVE</b>	<b>97</b>
Safety instructions	32	<b>Cleaning of dust filter</b>	<b>98</b>
Personnel Qualification	32	<b>Certification</b>	<b>99</b>
Risk of electric shock!	32	<b>General</b>	<b>100</b>



# Introduction

These instructions ensure safe and efficient handling of the convector. These instructions are an integral part of the equipment and must be kept in the immediate vicinity of the equipment and must be available to personnel at all times. All personnel must read this manual carefully before starting any work on the equipment. The basic prerequisite for safe work is to follow all the safety and other instructions contained in this manual. In addition, all local occupational health and safety regulations apply, as well as the general safety regulations governing the use of the equipment. The illustrations in this manual are for basic understanding; technical designs maybe be subject to change.

EN

## Explanation of symbols

						
<b>Risk of electric shock</b> This symbol appears in front of activities where there is a risk of electric shock.	<b>Warning</b> This symbol appears where dangerous situations may occur.	<b>Important notice</b> This symbol appears where damage to the unit or surrounding property may occur.	<b>Important note</b>	<b>Signalling LED light on keyboard not lit</b>	<b>Shining signalling LED light on the keyboard</b>	<b>Flashing signalling LED light on the keyboard</b>

Tab. 1 – Symbols in the manual

## Safety

### Correct use of the KORAWALL Direct and Energy convectors

The KORAWALL wall-mounted heating convector with fan is designed for heating and cooling in dry and frost-proof rooms. The convector is also suitable for low-temperature heating systems. The convector must be connected to the heating/cooling system and the building's electrical network. The KORAWALL convector is not intended for drying laundry, storing small objects, or for resting people or animals. The KORAWALL convector is not intended for use in wet areas such as swimming pools, bathrooms, conservatories, etc. The KORAWALL convector is used for heating or cooling. However, passive cooling is only possible in a non-condensing zone, i.e. above the dew point temperature. The unit housing lacks a built-in condensate drain, and condensate must be prevented from forming in the convector.

### Safety instructions

Always follow the safety instructions in this manual. Failure to comply with safety regulations, warnings, and instructions may result in injury, death of persons, or damage to property or to the heater or its accessories.

### Personnel Qualification

- The electrical installation design must be carried out by a appropriately qualified person and must comply with the relevant standards.
- The KORAWALL convector must only be installed, connected, and commissioned by a trained professional.
- **All work on electrical equipment may only be carried out by personnel with the appropriate electrical qualifications and the necessary familiarity with the equipment.**
- The convector must be assembled and installed in accordance with the general building, safety, and installation regulations and standards in force at the location.
- Any interventions to the convector and its repairs may only be carried out by a specialist with the appropriate electrical qualifications, who is also trained for this purpose by the convector manufacturer.

### Risk of electric shock! KORAWALL Energy WVE

- Contact with live parts can cause fatal electric shock.  
Damage to insulation or electrical components can lead to fatal injury.
- Work on the electrical system should only be performed by qualified electricians



Danger of fatal electric shock!

- If the insulation is damaged, immediately disconnect the system from the power supply and have it repaired. Replace damaged parts only with original parts from the convector manufacturer.
- Avoid moisture on live parts, as this can cause short circuits.
- Ground the convector properly.
- Installation, maintenance, and servicing should be carried out with the convector disconnected from the mains. Prevent accidental restart.

## General

- Children under 3 years of age should be prevented from accessing the device unless they are under constant supervision.
- This appliance may be used by children aged 8 years and older!
- Children from 3 to 8 years old may operate the appliance only if it is installed in the normal operating position and if they are supervised. They must not remove the front cover, clean the appliance, or carry out maintenance or servicing.
- Persons with reduced physical, sensory, or mental abilities, or with lack of experience and knowledge may operate the convector only if they are supervised or have been instructed in the safe use of the appliance and understand the potential hazards.

## Protection against frost

- If the convectors are not used for a long period of time (e.g. in winter), disconnect them from the power supply. Protect the convector from freezing.



**Prevent the heat exchanger from freezing. When used in unheated spaces, there is a risk of the heat exchanger freezing.**

## The right operating environment

- KORAWALL convectors are designed exclusively for indoor use. This means in a dry environment where there is no expectation of higher humidity and no other substances affecting the formation of corrosion are present.
- In particular: residential and non-residential interiors, office buildings, halls, production areas.
- Never use the device in wet areas such as swimming pools, winter greenhouses, botanical gardens, greenhouses, bathrooms, wellness centres, thermal baths, outdoor storage areas.
- Never use the device in rooms with an explosive atmosphere.
- Never use the unit in a chemically aggressive or corrosive atmosphere (e.g. sea air).
- Never use the unit over electrical equipment (e.g., junction boxes, computers, or other electrical equipment) or contacts that are not drip-proof.
- Do not place the convector over an electrical outlet.
- Never use the device in areas with high dust levels.
- Ensure that the air flow circulates freely.



**In case of improper use as described below, there is a risk of limitation or malfunction of the device.**

## Commissioning

- Before commissioning, the electrical equipment must be initially inspected according to the relevant national standards. During the period of operation, the user is obliged to ensure that regular inspections of the electrical equipment are carried out within the specified intervals according to the relevant national standards.
- Before the first start-up, check according to the chapter **Check before first start-up** (p 41)

## General

- Do not block the air inlet and outlet. The unit may overheat and destroy the control unit, fans or power supply.
- Do not sit on the convector, do not climb on it, and do not place any objects on it.
- Do not make any modifications to the convector to alter its function.
- **ATTENTION:** Some parts can get very hot and cause burns (e.g. heat exchanger)!
- When installing, maintaining or servicing the convector, use protective work equipment.
- Some parts of the convector may contain sharp parts.

# Technical parameters

EN


KORAWALL Direct WVD xxx/45/11							
Length [mm]	600	750	1 000	1 250	1 500	1 750	2 000
Width [mm]				110			
Height [mm]				450			
Heat output [W] 75/65/20 °C	190–1 688	278–2 467	424–3 766	570–5 064	716–6 363	862–7 661	1008–8960
Cooling output[W]	19–267	28–391	42–596	57–802	71–1008	85–1213	100–1419
Sound pressure [dB]	23.2–40.8	24.9–42.3	26.3–43.9	26.7–44.9	28.7–46.4	30.2–47.6	30.5–48.2
Weight [kg]	11.5	14.5	18.5	23.5	27.5	31.5	36.5
Water volume [l]	0.6	0.8	1.1	1.4	1.7	2.0	2.4
Connecting thread	2x G1½ female thread						

## Operating conditions

Max. operating pressure [MPa]	1.2
Max. and min. operating temperature [°C]	16–90
Max. and min. inlet air temperature	5–40
Max. and min. air humidity [%]	20–60

## Electrical parameters

Rated voltage of the convector [V]	24 DC						
Class of protection	III						
Ingress protection	IP 20						
External mains power supply	230 V AC/24 V DC/1A, protection class II, round plug Ø 5.5/2.1 mm						
Rated input power [W]	5.7	6.2	10.3	12.4	13.2	17.1	18.4
Rated current [A]	0.2	0.26	0.43	0.52	0.55	0.72	0.78
Fan voltage [V]	24 DC						
Number of fans	1	1	1	1	1	2	2



Tab. 2 – Technical parameters of the KORAWALL Direct WVD convectors

**KORAWALL Energy WVE xxx/45/11**


Length [mm]	600	750	1 000	1 250	1 500	1 750	2 000
Width [mm]				110			
Height [mm]				450			
Heat output [W] 75/65/20 °C	190–1 688	278–2 467	424–3 766	570–5 064	716–6 363	862–7 661	1 008–8 960
Cooling output [W]	19–267	28–391	42–596	57–802	71–1 008	85–1 213	100–1 419
Sound pressure [dB]	23.2–40.8	24.9–42.3	26.3–43.9	26.7–44.9	28.7–46.4	30.2–47.6	30.5–48.2
Weight [kg]	11.5	14.5	18.5	23.5	27.5	31.5	36.5
Water volume [l]	0.6	0.8	1.1	1.4	1.7	2.0	2.4
Connecting thread				2x G½ female thread			

**Operating conditions**

Max. operating pressure [MPa]	1.2
Max. and min. operating temperature [°C]	16–110
Max. and min. inlet air temperature	5–40
Max. and min. air humidity [%]	20–60

**Electrical parameters**


Rated voltage of the convector [V]	230 AC						
Power frequency [Hz]	50/60						
Class of protection	I						
Ingress protection	IP 20						
Internal mains power supply	230 V AC / 24 V DC / 1,5 A						
Rated input power [W]	6.0	6.8	11.2	13.5	14.4	18.7	21.2
Rated current [A]	0.026	0.033	0.048	0.059	0.066	0.087	0.10
Fan voltage [V]	24 DC						
Number of fans	1	1	1	1	1	2	2




Tab. 3 – Technical parameters of the KORAWALL Energy WVE convector



Max. 90 °C




Max. 1.2 MPa




EN

## Contents of standard delivery KORAWALL Direct WVD


1x





Mounting template



1x



1x



1x



4x




4x




4x

## Optional accessories




REG-TMS



REG-TMA




REG-TCW



Max. 90 °C




Max. 1.2 MPa




EN

## Contents of standard delivery KORAWALL Energy WVE


1x




Mounting template



## Optional accessories



REG-TMS




REG-TMA



REG-TCW

## Mounting dimensions



	L [mm]	X [mm]
WVx-060/45/11	600	493
WVx-075/45/11	750	643
WVx-100/45/11	1 000	893
WVx-125/45/11	1 250	1 143
WVx-150/45/11	1 500	1 393
WVx-175/45/11	1 750	1 643
WVx-200/45/11	2 000	1 893

## Installation – connection to the heating system

### Installation of the convector

#### Construction part

Install the convector according to the enclosed installation instructions.

- 2 persons are required to install the unit.
- Make sure the convector is firmly anchored to the wall.
- The convector must be placed horizontally, at least 10 cm above the ground. There should be at least 10 cm clearance next to the unit (to accommodate the thermostatic head, ease of installation and handling of the cover).
- Make sure the air can circulate freely.

The convector may contain sharp parts. Wear protective equipment.

## Connection to the heating system

When connecting to the heating system, follow the enclosed installation instructions.

- Connection to the heating system is possible on right bottom or left bottom.
- When using LM connection and regulation fittings, use the mounting template.
- Route the piping to avoid mechanical stress on the heat exchanger and to ensure that the unit is easily accessible for maintenance and repair.
- Seal and tighten the joints. Avoid shearing and twisting the connection nuts.
- Tighten all threaded joints and check for live connections after pipe installation.
- Bleed the exchanger.
- Perform a pressure test according to the standards of the relevant country.
- Use the correct tools.


EN

## Connecting the KORAWALL Direct WVD to the electrical system

The convector is connected via an external power supply to a standard socket. It is connected to the convector by a connection port (jack Ø 5.5/2.1 mm), located inside the convector.

- Equip the electrical network with the circuit breaker required according to the values in Tab. 2 Technical parameters of the KORAWALL Direct WVD convector and according to the standards of the country.

### Electrical diagram of the KORAWALL Direct WVD convector



- 1 control keypad for heating/cooling fan speed
- 2 convector control unit
- 3 power supply 230 V AC/24 V DC
- 4 connection connector
- 5 tangential fans with EC regulation
- 6 thermostatic and connection fitting

- To ambient temperature sensor
- Tv water temperature sensor in the heat exchanger

## Connecting the KORAWALL Energy WVE to the electrical system

According to the wiring diagram, connect the 230 V AC mains supply voltage to the voltage source inside the convector.

- Equip the electrical network with the circuit breaker required according to the values in *Tab. 3 – Technical parameters of the KORAWALL Energy WVE convector* and according to the standards of the country.

- Connect the electrical voltage to the **L**, **N** and **PE** connectors.


- Make sure the convector is properly grounded!

- Check that the cables are connected correctly and firmly.

- Check that the power supply and the terminal block are covered with the correct marked cover plate.

The convector must be assembled and installed in accordance with the general building, safety installation regulations and standards in force at the location.

### Electrical diagram of the KORAWALL Energy WVE convector



1 control keypad for heating/cooling fan speed

2 convector control unit

3 power supply 230 V AC/24 V DC

= L, N and PE terminals for connection to the mains

4 tangential fans with EC regulation

5 thermostatic and connection fitting

To ambient temperature sensor

Tv water temperature sensor in the heat exchanger

# Check before the first start-up

When the instrument is first put into operation, make sure that all the requirements are met so that the instrument can operate safely and in accordance with its intended use.

EN

## Mounting part

- Check that the convector is firmly and securely anchored.
- Check the horizontal installation/hanging of the convector.
- Check that all components are correctly fitted.
- Check that all dirt has been removed, e.g. from the packaging or the construction site.

## Connecting the heating medium

- Check that all inlet and outlet pipes are connected correctly.
- Check that the heat exchanger is vented and the vent screw is tightened.
- Check for leaks (pressure test and visual inspection).
- Check that all shut-off valves fitted are open.
- Check that all valves are working properly and are set correctly.
- Check that the cooling system is set to prevent condensation on the heat exchanger.

## Electrical part


- Check that the connector from the power supply is correctly inserted into the connection connector located inside the convector (WVD).
- Check the correct wiring according to the wiring diagram (WVE).
- Check that the connection cable between the keyboard and the control unit is connected correctly.
- Check the correct sensor mounting connections. The sensor on the heat exchanger should have a tight contact with the pipe (WVD).
- Check the grounding of the convector including the front cover (WVE).

## Airflow

- Check that the airflow is not obstructed and remove obstructions if necessary.
- Check that the filter is properly attached and clean of debris. Reposition or clean as necessary.

# Service

## Function description



Tab. 4 – Description of the control keypad

- A control keypad
- B signalling LED lights
- C control button

## Commissioning

After the connection to the mains, an internal function check will be run on the control unit and the connected fans. (initial initialization). Immediately after the power supply is connected, all fans will spin for 10 seconds. All the signalling LED lights on the control keypad will flash one by one

Stage of speed	Signalling LED light	Fan speed
0	○ ○ ○ ○ ○	0 – off
1	● ○ ○ ○ ○	1 – minimum
2	● ● ○ ○ ○	2 – low
3	● ● ● ○ ○	3 – medium
4	● ● ● ● ○	4 – high
5	● ● ● ● ●	5 – maximum

Tab. 5 – Fan speed indication

## Fan speed selection

Fan speed selection Short, repeated press of the control button

Heating mode LEDs are lit continuously

Cooling mode LEDs are blinking

Changing between heating and cooling modes Hold the control button for 10 seconds

## Changing the “heating/cooling” mode

To change the mode, hold the control button down for 10 seconds. In the “heating” mode, the signalling LED lights are permanently lit; in the “cooling” mode, the signalling LED lights flash

### “Heating” mode

The fans are controlled based on the temperature of the heating element (Tv sensor) and the ambient temperature (To sensor), see Tab. – 6. The convector can be equipped with a manually operated thermostatic head.

Ambient temperature sensor To	Temperature sensor on the heat exchanger Tv	Status of fans
Ambient temperature 0–60 °C	Water temperature 0–28 °C	Fans off (cold wa er)
Ambient temperature 0≤27 °C	Water temperature ≥32 °C	Fans on
Ambient temperature 0<27 °C	Water temperature ≤28 °C	Fans off (cold wa er)
Ambient temperature ≥27 °C	Water temperature 0–90 °C	Fans off (hea ed room)

Tab. 6 – Heating mode

### “Cooling” mode

The fans are controlled according to the temperature of the heating element (Tv sensor) and the ambient temperature (To sensor). The function is described in Tab. 7. The convector can also be equipped with a special thermostatic head, adapted for cooling. The value for cooling is set on the head. If the unit is equipped with an ordinary thermostatic head, the head must be manually set to the maximum possible value of the thermostatic head in the “cooling” mode.

**⚠ In the cooling mode, condensate formation must be prevented to avoid short-circuiting and destroying the fans. The temperature of the cooling medium must be above the dew point of the room air to prevent condensation from forming on the heat exchanger. The convector is not an air conditioning unit and does not have a condensate drain.**

Ambient temperature sensor To	Temperature sensor on the heat exchanger Tv	Status of fans
Ambient temperature <24 °C	Water temperature 0–90 °C	Fans off (low ambient emperature)
Ambient temperature ≥24 °C	Water temperature ≤22 °C	Fans on
Ambient temperature <23 °C	Water temperature ≤23 °C	Fans off (cold oom)
Ambient temperature ≤23 °C	Water temperature >23 °C	Fans off (wa er too hot)

Tab. 7 – Cooling mode

## Maintenance

- Maintenance should be carried out with the convector disconnected from the mains. Avoid restarting. Unauthorized or uncontrolled restarting of the device may result in serious injury or death.
- Before fitting the outer cover with the control keypad, make sure that the cover is properly grounded and the cable is connected to the keypad.
- Before restarting, make sure that all components are in the correct place and there is no danger to the person operating the convector.
- Vent the convector regularly.
- Regularly remove dust from the exchanger (vacuum cleaner, broom).
- Regularly remove dust from the convector. Do not use abrasive cleaners or solvents for cleaning.
- Any intervention in the control electronics, power supply and fans must only be carried out by a qualified electrician.

Do not make any modifications to the convector that will alter its function. For additional maintenance requirements for Licon convectors, please visit [www.licon.cz](http://www.licon.cz) or [www.korado.cz](http://www.korado.cz) for the current Warranty and Post-Warranty Terms and Conditions.

# Equipment malfunctions

## Diagnostic mode

The control unit automatically checks the function of the temperature sensors and the operation of the fans. If a fault is detected, the fans are switched off and the signalling LED lights on the keypad indicate the cause of the fault *Tab. 8 – Diagnostic mode*.

Signalling LED light	Failure	Description of the defect
	Temperature sensor on the heat exchanger <b>Tv</b>	1) Faulty sensor 2) Broken/shorted sensor cable 3) Disconnected sensor connector
	Ambient temperature sensor <b>To</b>	1) Faulty sensor 2) Broken/shorted sensor cable 3) Disconnected sensor connector
	Fan	1) Defective fan 2) Interrupted fan supply cable 3) Fan cable not connected

EN

*Tab. 8 – Diagnostic mode*

If a fault is detected, visually check the supply cables of the temperature sensors and fans. If you cannot find the cause of the fault, contact your dealer or the manufacturer of the convector.

## Primary initialization did not take place

- Check the mains supply connection to the power supply (WVE)
- Check the low voltage supply connection from the power supply to the control unit – terminals **+V**, **-V** (WVE)
- Check the power cable connection from the control unit to the keypad

## Fans do not work – “heating” mode

The heating water temperature is > 32 °C:

- Check the position and mounting of the temperature sensor **Tv** on the heat exchanger. The sensor must be placed on the upper tube of the heat exchanger, and the sensor must be tightly adjacent to the surface of the tube.

Heat exchanger temperature < 32 °C:

- Check the heating medium supply.

The ambient temperature is < 27 °C:

- Check the ambient temperature sensor **To**. Air must flow freely around the sensor, and the sensor must not be covered with dust.

## Fans not working – “cooling” mode

The heating water temperature is < 23 °C:

- Check the position and mounting of the temperature sensor **Tv** on the heat exchanger. The sensor must be placed on the upper tube of the heat exchanger, and the sensor must be tightly adjacent to the surface of the tube.

The temperature at the heat exchanger is > 23 °C

- Check the cooling medium supply.

The ambient temperature is > 24 °C:

- Check the ambient temperature sensor **To**. Air must flow freely around the sensor, and the sensor must not be covered with dust.


## Old electrical and electronic equipment



Electrical or electronic equipment that is no longer fit for use must be collected separately and sent for environmentally friendly recycling (European Directive on old electrical and electronic equipment). Use nationally established return and collection systems to dispose of old electrical or electronic equipment.

**cz** Montáž – stavební část **sk** Inštalácia – stavebná časť **en** Assembly – construction part **de** Montage – Bauteil **fr** Montage – partie construction **ru** Монтаж – строительная часть



**cz** Připojení na rohovou LM armaturu **sk** Pripojenie na rohovú LM armatúru **en** Connection to elbow LM-valve  
**de** Anschluss an LM Ventil Direktausführung **fr** Raccordement à la vanne LM équerre **ru** Подключение к угловой LM арматуре





1x

Montážní šablona, Montážna šablóna,  
Mounting template, Montageschablone,  
Gabarit de montage, Монтажный шаблон


**2)**




**3)**




4)



5)




**6)**




+




**7)**



8)




9)



**CZ** Pravé připojení **SK** Pravé pripojenie

**EN** Right connection **DE** Rechter Anschluss

**FR** Raccordement droit **RU** Соединение справа



**CZ** Manuál LM armatury

**SK** Manuál LM armatury

**EN** LM valve manual

**DE** Anleitung für das LM-Ventil




**FR** Instructions pour la vanne LM

**RU** Инструкция по эксплуатации  
LM-клапана



10)




- CZ** Připojovací šroubení není součástí balení
- SK** Pripojovacie šróbenie nie je súčasťou balenia
- EN** Connection fitting a e not a part of the package
- DE** Anschlussverschraubung ist nicht im Lieferumfang enthalten
- FR** Vis de raccordement ne sont pas inclus avec les accessoires
- RU** Соединительное резьбовое соединение не входит в комплект стандартной поставки




11)





12)




13)



14)



**cz** Odvzdušněte  
**EN** Bleed  
**DE** Entlüften  
**FR** Purgez  
**RU** Удаляте воздух



**cz Připojení na přímou LM armaturu**


**sk Pripojenie na priamu LM armatúru**

**en Connection to straight LM-valve**

**de Anschluss an LM Ventil Eckausführung**

**fr Raccordement à la vanne LM droite**



**ru Подключение к прямой LM арматуре**




**2)**

1x

Montážní šablona  
Montážna šablóna  
Mounting template  
Montageschablone  
Gabarit de montage  
Монтажный шаблон





**3)**




**4)**


2x




5)



6)







7)




8)




**9)****10)****11)**



12)




13)




14)




**15)**



a)



b)





**CZ** Odvzdušněte  
**EN** Bleed  
**DE** Entlüften  
**FR** Purgez  
**RU** Удалите воздух


**CZ Nasazení předního krytu** **SK Nasadenie predného krytu**  
**EN Mounting of the front cover** **DE Anbringung der vorderen Abdeckung**  
**FR Installation du caisson** **RU Установка передней крышки**

**KORAWALL Direct WVD**




**1)**



**2)**




**3)**




## KORAWALL Energy WVE

1)






2)



**CZ Čištění prachového filtru** **SK Čistenie prachového filtra**

**EN Cleaning of dust filter** **DE Reinigung des Staubfilters**

**FR Nettoyage du filtre antipoussière** **RU Чистка пылевого фильтра**



**CZ POZOR!** Hrozí utržení kabelu. Délka kabelu 1 m.

**SK POZOR!** Hrozí odtrhnutie kábla. Dĺžka kábla 1 m.

**EN WARNING!** Cable detachment risk. Cable length 1 m.


**DE ACHTUNG!** Es besteht die Gefahr eines Kabelbruchs. Kabellänge 1 m.

**FR ATTENTION !** Le câble risque de se rompre.

Longueur du câble 1 m.

**RU ВНИМАНИЕ!** Существует риск обрыва кабеля.

Длина кабеля 1 м.



<b>CZ, BG, DE, DK, EE, ES, FR, HR, GB, LT, LV, NL, PL, RU, SK, UA</b>	
<b>1 Heating system in building</b>	
<b>2 Reaction to fire</b>	A1
<b>3 Release of dangerous substances</b>	NONE
<b>4 Pressure tightness</b>	no leakage at $1,3 \times MOP$
<b>5 Resistance to pressure</b>	no breakage at $1,69 \times MOP$
<b>6 Maximum operating pressure (MOP)</b>	1200 kPa
<b>7 Surface temperature</b>	Maximum 90 °C
<b>8 Rated thermal outputs</b>	$\Phi_{\text{ref}} \Phi_{30} [\text{W}]$
<b>9 Thermal output in different operating conditions (characteristic curve)</b>	$\Phi = K_m \cdot \Delta t^n [\text{W}]$
<b>10 Durability as:</b>	
<b>11 Resistance against corrosion</b>	No corrosion after 100 h humidity
<b>12 Resistance against minor impact</b>	Class 0

**CZ** 1. V otopných soustavách v budovách / **2.** Reakce na ohře: A1 / **3.** Uvoľňovanie nebezpečných látiek: NEN / **4.** Těsnost: Žádná netěsnosť otopného telesa při 1,3 násobku nejvyššího přípustného provozního tlaku [kPa] / **5.** Odolnosť proti prétaku: Žádné známky roztržení otopného telesa při 1,69 násobku nejvyššího přípustného provozního tlaku [kPa] / **6.** Nejvyšší přípustný provozní tlak / **7.** Povrchová teplota: Nejvíše 90 °C / **8.** Teplelné výkony / **9.** Teplelný výkon za odlišných provozních podmínek (charakteristická krivka) / **10.** Trvanlivost jako / **11.** Odolnosť proti korozii: Žádná korozie po vystavení vlhkosti na dobu 100 hodin / **12.** Odolnosť proti mechanickému poškození menšími rázamy: Trieda 0

**BG** 1. Отопни системи в сгради / **2.** Реакция на огън: А1 / **3.** Освобождаване на опасни вещества: ОТГОВАРИ НА НОРМА / **4.** Изпитателно налягане:  $1,3 \times$  от максимално работно налягане [kPa] / **5.** Устойчивост среду налягане:  $1,69 \times$  от максимално работно налягане [kPa] / **6.** Максимално работно налягане / **7.** Температура на повърхността: Максимално 90 °C / **8.** Номинална топлинна мощност / **9.** Топлинна мощност при различни експлоатационни условия (характеристична крива) / **10.** Продължителност като / **11.** Устойчивост преди корозия: Лицес на корозия след 100 h влажност / **12.** Устойчивост при минимален натиск: Клас 0

**DE** 1. Heizsysteme in Gebäuden / **2.** Brandverhalten: A1 / **3.** Freisetzen von gefährlichen Stoffen: BESTÄNDEN / **4.** Druckdichtigkeit: keine Undichtigkeit bei 1,3fachem maximal zulässigem Betriebsdruck [kPa] / **5.** Druckfestigkeit: kein Riss bei  $1,69 \times$  maximal zulässigem Betriebsdruck [kPa] / **6.** Maximal zulässiger Betriebsdruck / **7.** Oberflächen temperatur: Maximal 90 °C / **8.** Nennwärmeverrichtung / **9.** Wärmeleistung unter verschiedenen Betriebsbedingungen (Kennlinie) / **10.** Widerstand / **11.** Korrosionswiderstand: Ohne Korrosion nach 100 Stunden im naßen Raum / **12.** Kleinschlagwiderstand: Klasse 0

**DK** 1. Varmesystemer i bygninger / **2.** Reaktion ved brand: A1 / **3.** Frigivelse af farlige stoffer: INGEN / **4.** Tryktæthed: Ingen lekkage ved  $1,3 \times MOP$  [kPa] / **5.** Modstandsdygtighed over for tryk: ingen brud ved  $1,69 \times MOP$  [kPa] / **6.** Maksimal driftstryk (MOP) / **7.** Overflade temperatur: maks. 90 °C / **8.** Nominal termisk effekt / **9.** Termisk effekt under forskellige driftsbedingelser (charakteristisk kurve) / **10.** Holdbarhed / **11.** Modstandsdygtighed over for korrosion: ingen korrosion efter 100 timer i fugtige omgivelser / **12.** Modstand mod mindre påvirkning: Klasse 0

#### **EE** 1. Hooneste küttesüsteemid / **2.** Tuletundlikkus: A1 / **3.** Ohtlike ainete eraldumine:

PUUDUB / **4.** Tiheus: 1,3-kordseks maksimaalse lubatud töötlööröhu [kPa] korral lekked puuduvad / **5.** Röhrikindlus: 1,69-kordseks maksimaalse lubatud töötlööröhu [kPa] korral radiatori purunemise määrgi puuduvad / **6.** Maksimaalne lubatud töötlööröhk / **7.** Pinna temperatuur: Maksimaalselt 90 °C / **8.** Soojuvõimsused / **9.** Soojuvõimsus teistustugustes töötümingutes (karakteristikuköver) / **10.** Püsivus / **11.** Korrosioonikindlus: Päras 100 tundi niiskuse möju korroosioon puudub / **12.** Välksemate löökide põhjustatud mehaanilise kahjustuse kindlus: Klass 0

**ES** 1. Sistemas de calefacción en edificios / **2.** Reacción al fuego: A1 / **3.** Liberación de sustancias peligrosas: NO HAY / **4.** Estanqueidad: Ninguna falta de estanqueidad en caso de presión de servicio máxima admisible multiplicada por 1,3 [kPa] / **5.** Resistencia a la sobrepresión: Ningunos signos de rotura del calentador en caso de presión de servicio máxima admisible multiplicada por 1,69 [kPa] / **6.** Presión de servicio máxima admisible / **7.** Temperatura superficial: 90 °C como máximo / **8.** Salidas de calor nominales / **9.** Salida de calor en condiciones de servicio diferentes (curva característica) / **10.** Durabilidad / **11.** Resistencia a la corrosión: Ausencia de corrosión tras 100 horas de exposición a la humedad/ **12.** Resistencia a daños mecánicos causador por golpes pequeños: Clase 0

**FR** 1. Systèmes de chauffage dans les bâtiments / **2.** Réaction au feu: A1 / **3.** Relâchement des substances dangereuses : CONFORME À LA NORME / **4.** Étanchéité à la pression : Aucune fuite de l'élément chauffant à 1,3 fois pression de service maximale admissible [kPa] / **5.** Résistance contre la surpression : 1,69 de la pression d'exploitation maximale [kPa] / **6.** Suppression d'exploitation maximale / **7.** Température de la surface : Maximum 90 °C / **8.** Puissance thermique nominale / **9.** Puissance thermique dans des diffé éntes conditions d'exploitation (la courbe caractéristique) / **10.** Résistance / **11.** Résistance à la corrosion: Sans corrosion après 100 h dans un milieu humide / **12.** Résistance contre une petite percussion: Classe 0

**GB** 1. Heating systems in buildings / **2.** Reaction to fire: A1 / **3.** Release of dangerous substances: NONE / **4.** Pressure tightness: no leakage at  $1,3 \times MOP$  [kPa] / **5.** Resistance to pressure: no breakage at  $1,69 \times MOP$  [kPa] / **6.** Maximum operating pressure (MOP) / **7.** Surface temperature: Maximum 90 °C / **8.** Rated thermal outputs / **9.** Thermal output in different operating conditions (characteristic curve) / **10.** Durability as / **11.** Resistance against corrosion: No corrosion after 100 h humidity / **12.** Resistance against minor impact: Class 0

**HR** 1. Sustavi za grijanje u zgradama / **2.** Reakcija na plamen: A1 / **3.** Oslobođanje opasnih tvari / **4.** Oslobođanje opasnih tvari: Bez propuštanja pri  $1,3 \times MOP$  [kPa] / **5.** Otpornost na tlak: Bez pucanja pri  $1,69 \times MOP$  [kPa] / **6.** Maksimalni radni tlak (MOP) / **7.** Površinska temperatura: Najviše 90 °C / **8.** Nazivna toplinska energija / **9.** Toplinska energija u različitim radnim uvjetima (radna krivulja) / **10.** Trajanost / **11.** Otpornost na koroziju: Bez korozije nakon 100 h vlažnosti / **12.** Otpornost na manje udare: Razred 0

**LT** 1. Pastatų šildymo sistemos / **2.** Reakcija į ugnį: A1 / **3.** Pavojingu medžiagų išskrydimas: ATITINKA STANDARTĄ / **4.** Bandymo slėgis:  $1,3 \times$  maksimalaus darbinio slėgio [kPa] / **5.** Atsparumas slėgiui:  $1,69 \times$  maksimalaus darbinio slėgio [kPa] / **6.** Maksimalus darbinis slėgis / **7.** Paviršiaus temperatūra: Maksimalai 90 °C / **8.** Vardinié šiluminė gala / **9.** Šiluminis galas skirtas ekspluatacijai esytiems sylgomis (būdingoji lygtis) / **10.** Atsparumas / **11.** Atsparumas korozijai: Be korozijos po 100 val. drėgnoje aplinkoje / **12.** Atspares nedideliam sutrenkimui: Kategorija 0

**LV** 1. Ēku apkures sistēmas / **2.** Reakcija uz ugni: A1 / **3.** Bistamo vielu izdalīšana: NAV / **4.** Hermetisksums: Kad 1,3 reiž pārsniegt maksimālu pieļaujamu darba spiedienu [kPa], radiatori ir hermetiski / **5.** Izturība pret spiedieniem: Kad 1,69 reiž pārsniez maksimālu pieļaujamu darba spiedienu [kPa], radiatoru bojājumi nav / **6.** Maksimālais pieļaujamais darba spiediens / **7.** Virsmas temperatūra: Maksimāli 90 °C / **8.** Siluma atdevē / **9.** Siluma atdevē esot atskirīgiem ekspluatācijas apstākļiem (raksturliķe) / **10.** Izturība kā / **11.** Izturība pret koroziju: Nekāda korozija pēc 100 standūm mitrumā / **12.** Izturība pret mehāniskāju bojājumu no mazākiem treicējiem: Klase 0

**NL** 1. Verwarming in gebouwen / **2.** Gedrag bij brand: A1 / **3.** Vrijlating van gevarelij en stoffen: VOLDOET AAN DE NORM / **4.** Druk dichtheid:  $1,3 \times$  van de maximale bedrijfsdruk [kPa] / **5.** Drukbestendigheid:  $1,69 \times$  van de maximale bedrijfsdruk [kPa] / **6.** Maximale bedrijfsdruk / **7.** Oppervlaktetemperatuur: maximaal 90 °C / **8.** Nominaal vermogen / **9.** Thermisch vermogen onder verschillende bedrijfsomstandigheden (karakteristieke vergelijking) / **10.** Duurzaamheid / **11.** Weerstand tegen corrosie: Zonder corrosie na 100 u vuchtigheid / **12.** Slagvastheid bij geringe impact: Klasse 0

**PL** 1. Uklady grzewcze w budynkach / **2.** Reakcja na ogień: A1 / **3.** Wypłaczanie substancji niebezpiecznych: SPEŁNIA NORMĘ / **4.** Naciśnięcie próbnie:  $1,3 \times$  maksymalnego ciśnienia roboczego [kPa] / **5.** Odporność na naciśnięcie:  $1,69 \times$  maksymalnego ciśnienia roboczego [kPa] / **6.** Maksymalne ciśnienie robocze / **7.** Temperatura powierzchni: Maksymalny 90 °C / **8.** Nominalna moc cieplna / **9.** Moc cieplna przy odrędnymi warunkami eksploatacyjnymi (rownanie charakterystyczne) / **10.** Odporność / **11.** Odporność na korozję: Bez korozji po 100 godzinach w środowisku wilgotnym / **12.** Odporność na niewielkie uderzenia: Klasa 0

**RU** 1. Системы отопления в зданиях / **2.** Реакция на огонь: A1 / **3.** Выделение опасных веществ: НЕТ / **4.** Герметичность под давлением: отсутствие утечки при 1,3 кратном максимального допустимого рабочего избыточного давления [кПа] / **5.** Устойчивость к избыточному давлению: отсутствие признаков разрыва отопительного прибора при 1,69 кратном максимального допустимого рабочего избыточного давления [кПа] / **6.** Максимальное допустимое рабочее избыточное давление / **7.** Температура поверхности: максимально 90 °C / **8.** Значения номинальной тепловой мощности / **9.** Топливная мощность при различных условиях работы (характерная кривая) / **10.** Долговечность / **11.** Устойчивость к коррозии: отсутствие коррозии после 100 часов пребывания в условиях повышенной влажности / **12.** Устойчивость к воздействию механического повреждения несильными ударами: Класс 0

**SK** 1. Teplélné sústavy v budovách / **2.** Reakcia na oheň: A1 / **3.** Uvoľnenie nebezpečných látok: NIE JE / **4.** Skúšobný tlak:  $1,3 \times$  maximálneho operačného tlaku [kPa] / **5.** Odolnosť proti tlaku:  $1,69 \times$  maximálneho operačného tlaku [kPa] / **6.** Maximálny preprávkový tlak / **7.** Teplota povrchu: Maximálne 90 °C / **8.** Menovitý teplý výkon / **9.** Teplý výkon za odlišných prevádzkových podmienok (charakteristická krivka) / **10.** Odolnosť voči korozii: Bez korózie po 100 h vlhkom prostredí / **12.** Odolnosť voči malému nárazu: Trieda 0

**UA** 1. Опаливальні системи в будівлях / **2.** Реакція на вогонь: А1 / **3.** Виділення небезпечних речовин: НЕМ / **4.** Герметичність:  $1,3 \times$  кратному перевищенню максимального робочого тиску [кПа] без порушення герметичності / **5.** Стійкість до перевищенню тиску: При  $1,69$ -кратному перевищенню максимального робочого тиску [кПа] без ознак розриву радіатора / **6.** Максимальний робочий тиск / **7.** Температура поверхні: Не більше 90 °C / **8.** Номінальна теплова потужність / **9.** Теплова потужність при різних режимах роботи (графіка характеристики) / **10.** Строк служби / **11.** Стійкість до корозії: Після 100 годин протягом 100 годин корозія відсутня / **12.** Стійкість до механічного пошкодження від незначних поштовхів: Клас 0

## **CZ Všeobecné informace**

- Výrobky se nesměj používat v agresivním prostředí (chlór, žíroviny či jiné chemikálie) nebo být takovými látkami „isti“ ny.
- Výrobky nesměj být umístěny v prostředí se zvýšenou vlhkostí (bazény, skleníky, apod.) pokud nejsou vyrobeny v úpravě, která je odolná tomuto prostředí.
- Výrobky musí být po zabudování pečlivě zakryty až do úplného ukončení všech stavebních prací, tak aby nedošlo k jejich následnému poškození i zneisti.
- Tepelný výměník je třeba pravidelně kontrolovat a udržovat v čistotě tak, aby nedošlo k jeho mechanickému poškození a následné celkové nefunkčnosti. V případě znečištění je nutné ho vhodným způsobem vyučítit (napr. vysavačem).
- Tělesa je nutné pravidelně odvzdušňovat. Pozor aby nedošlo k opaření horkou vodou, která mže ze pí odvzdušnění vystřknout. Soustava musí být vždy zabezpečena expanzním a pojistným zařízením.
- Podrobnější informace jsou k dispozici v provozních a záručních podmínkách, které jsou ke stažení na [www.licon.cz](http://www.licon.cz) nebo na vyžádání u obchodního oddělení společnosti LICON.

## **SK Všeobecné informácie**

- Výrobky sa nesmú používať v prostredí s agresívnu atmosférou (chlór, žíroviny alebo iné chemikálie) ani sa takýmito látkami „isti“.
- Výrobky sa nesmú umiesťovať do prostredia so zvýšenou vlhkosou (bazény, skleníky a pod.), ak nie sú vyrobené v úprave, ktorá je odolná proti tomuto prostrediu.
- Výrobky sa musia po zabudovaní dôkladne zakryť až do úplného skončenia všetkých prác, aby nedošlo k ich následnému poškozeniu i zneisti.
- Tepelný výmenník je potrebné pravidelné kontrolovať a udržiavať v istote tak, aby nedošlo k jeho mechanickému poškozeniu a následnej celkovej nefunkčnosti. V prípade zneisti je nutné ho vhodným spôsobom vyučistiť (napr. vysávačom).
- Telesa je nutné pravidelné odvzdušniť ova“. Pozor, aby nedošlo k obareniu horúcou vodou, ktorá môže pri odvzdušnení vystreknuť. Sústava musí byť vždy zabezpečená expanzním a pojistným zařízením.
- Podrobnějšie informácie sa nachádzajú v Prevádzkových a záručných podmienkach, ktoré sa dajú stažať z webovej stránky [www.licon.cz](http://www.licon.cz) alebo sú dostupné na vyžiadanie od obchodného oddelenia spoločnosti LICON.

## **DE Allgemein**

- Die Produkte dürfen weder in aggressiver atmosphärischer Umgebung angewendet werden (Chlor, Ätzmittel oder andere Chemikalien) noch mit solchen Stoffen gereinigt werden.
- Die Produkte dürfen nicht in Umgebungen mit erhöhter Feuchtigkeit platziert werden (Schwimmbäcken, Gewächshäuser u. ä.), soweit sie nicht in einer Ausführung hergestellt sind, welche gegen diese Umgebung beständig ist.
- Die Produkte müssen nach dem Einbau bis zur völligen Beendigung aller Bauarbeiten sorgfältig abgedeckt werden, damit es zu keiner anschließenden Beschädigung oder Verschmutzung kommt.
- Der Wärmetauscher muss regelmäßig kontrolliert und sauber gehalten werden, so dass es nicht zu dessen mechanischer Beschädigung und nachfolgender Nichtfunktionsfähigkeit kommen kann. Bei einer Verschmutzung muss er in geeigneter Weise gereinigt werden (z.B. mit einem Staubsauger).
- Der Körper muss regelmäßig entlüftet werden. Achtung, bei der Entlüftung kann heißes Wasser austreten, dass zu Verbrühen führen kann. Das System muss immer mit einer Expansions- und Sicherheitsanlage abgesichert sein.
- Nähere Informationen sind in den Betriebs- und Garantiebedingungen zu finden, welche auf [www.licon.cz](http://www.licon.cz) heruntergeladen werden können oder auf Wunsch bei der Geschäftsabteilung der Gesellschaft LICON zur Verfügung stehen.

## **KORADO, a.s.**

Bř Hubálk° 869

560 02 „eská T“ebová, Czech Republic

e-mail: [info@korado.cz](mailto:info@korado.cz)

CZ info linka (zdarma): 800 111 506

**[www.korado.cz](http://www.korado.cz)**



## **EN General**

- The products should not be used in aggressive atmospheric environment (chlorine, caustic or other chemicals) or cleaned with such substances.
- The products may not be located in increases humidity environment (swimming pools, greenhouses, etc.) if the manufactured version is not resistant to such environment.
- To avoid subsequent damage or fouling the products must be carefully covered after installation until the complete cessation of all building work.
- Inspection and cleaning of the heat exchanger is necessary in order to prevent mechanical damage and subsequent total inoperability. If cleanliness is not maintained, the heat exchanger must be cleaned in the appropriate manner (e.g. with a vacuum cleaner).
- Any air trapped in the units must be regularly released. Take care not to scald one's self with hot water that may spray out when releasing air. The system must always be fitted with an expansion control valve.
- Detailed information is available in Operational and guarantee conditions, downloadable on [www.licon.cz](http://www.licon.cz) or upon request from LICON.

## **FR Informations générales**

- Les produits ne peuvent pas être utilisés dans un environnement atmosphérique agressif (chlore, caustiques ou autres produits chimiques) ou être nettoyés avec de tels produits ou substances.
- Les produits ne peuvent pas être installés dans un environnement à haute humidité relative (piscines, jardins d'hiver, etc.) s'ils ne sont pas produits en version résistante à ce type d'environnement.
- Les produits doivent être soigneusement couverts après leur encastrement jusqu'à la terminaison complète de tous travaux de construction pour éviter leur pollution ou endommagement conséquent.
- L'échangeur de chaleur doit être régulièrement contrôlé et conservé propre pour que sa détérioration mécanique n'ait pas lieu, entraînant son disfonctionnement total. En cas d'encrassement, il faut le nettoyer de manière appropriée (par ex. à l'aide d'un aspirateur).
- Les corps doivent être désaérés régulièrement. Faites attention à ne pas vous ébouillanter par de l'eau chaude qui peut alors gicler. L'ensemble doit être toujours sécurisé par un dispositif d'expansion sécuritaire.
- Les informations détaillées sont disponibles dans les Conditions de service et de garantie – à télécharger depuis le site [www.licon.cz](http://www.licon.cz) ou sur demande au service commercial de la société LICON.

## **RU Общие правила**

- Продукты нельзя устанавливать в агрессивных средах (хлор, щелочь или другие химические в щ. ства), таки в щ. ства таки нельзя использовать для чистки.
- „деляя нали“ я устанавливаю в среде с „овы“ ннон влат ностье (басс. йны, парники и т.д.), сли они сп „иально н“ редусмотр ны для тако среды.
- После установки изделия долт ны быть тщательно акрьты в“ лоть до „оного а р‘ ния вс х строительных работ, чтобы н“ роизо“ ло их „овр тд н или агря н н .
- † „лооби нник н обходимо р гулярно “ров рять и сод ртать в чистот такими образом, чтобы он н был м ханических „овр тд н с посл дубц ѕ от р ѕ ..ункциональности. При агрэзии нии гон обходимо соот тствую ѕим образом вычистить (на рим р, „ыл сосом).
- „ р гистра н обходимо р гулярно вы“ ускат во духа. –ними ! Буди остророт ны, чтобы н обѣ чья горяч ѕ водоб., которая ра - бры гива тся во вр ми бы“ уска во духа. фист ма в гда долт на быть ащиц на посредством расширительного и „редохранительного“ кла“ анов.
- Бол „одробиа ин..ормаии мо“ ной найти в/ абочих и гарантитных условиях, которые мо“ ной сканать на в бстрии• [www.licon.cz](http://www.licon.cz) или а“ росить у торгового отдела ко“ ании LICON.



## **LICON s.r.o.**

Průmyslová zóna Sever, Svárovská 699,

463 03 Stráž nad Nisou, Czech Republic

e-mail: [info@licon.cz](mailto:info@licon.cz)

**[www.licon.cz](http://www.licon.cz)**



member of KORADO Group