
LIST OF BRACKETS

Bench convectors KORALINE in Exclusive LKX and Economic LKE versions are supplied as standard with stands for a finished floor. Other fastening methods include brackets for a subfloor or brackets for mounting bench convector on a wall.



Wall bracket

- optional accessories
- the distance between the wall and unit is 10-30 mm
- from the length of 2 000 mm, it is necessary to order packages of 3 pieces









80

130

180 230

Stand cover

width


- optional accessories
- stand covers are supplied by 2 pieces and designed for covering end stands for a finished floor
- from the length of 2 000 mm, bench convectors KORALINE (Economic, Exclusive) are supplied with central stand





Dimensions are stated in mm.


Bracket cover dimensions









Fastening of KORALINE LKX and LKE floor brackets to a finished floor




Fastening of KORALINE LKX and LKE wall brackets to a wall



Fastening of KORALINE LKX and LKE brackets to a subfloor



Fastening of KORALINE LD with board to a finished floor



Minimum distance from the wall 100 mm applies to both LKD types.

Тур	Α	В
LDX-XXX-30-26	150	L - 170
LDX-XXX-45-31	206	L - 150

L = 1 000, 1 200, 1 400, 1 600, 1 800, 2 000 mm